

Outside Wall Switch
CM-45/455SE1
(or similar)

Inside
'Push To Open (always unlocks & opens door)
& Push to Lock' combination Switch
CM-2520/4855SE1
(or similar)

Aura Dip Switch Settings

Color Select

1	Red	IDL
2	G/B	
3	Red	ACT
4	G/B	

ON →

Enable

4		LOC/REM
3		
2		RELAY
1		


ON ←

SPEAKER

Camden DOOR CONTROLS		5502 Timberlea Blvd. Mississauga, Ontario L4W 2T7	
SCALE: NONE	DRAWN BY: JML	DATE: May 14, 2018	REVISED:
WC13AXFM Washroom Package Wiring Diagram (normally unlocked)			
DRAWING No: CX-WC13AXFM-7		FILENAME: CX-WC13AXFM-7.AI	

For Normally Locked Door, see over...

Part # 40-82D016



Outside Wall Switch CM-45/455SE1 (or similar)

Inside 'Push To Open (always unlocks & opens door) & Push to Lock' combination Switch CM-2520/4855SE1 (or similar)

Aura Dip Switch Settings

Color Select

1	Red	IDL
2	G/B	
3	Red	ACT
4	G/B	

ON →

Enable

4		LOC/REM
3		
2		RELAY
1		

ON ←

SPEAKER

Camden DOOR CONTROLS

5502 Timberlea Blvd. Mississauga, Ontario L4W 2T7

SCALE: NONE	DRAWN BY: JML	DATE: May 14, 2018	REVISED:
-------------	---------------	--------------------	----------

WC13AXFM Washroom Package Wiring Diagram (normally locked)

DRAWING No: CX-WC13AXFM-8	FILENAME: CX-WC13AXFM-8.AI
---------------------------	----------------------------